

Install guide for Kinman Tele pickups (3C) in Fender Baja Tele S1 system.

05-Apr-08

Neck pickup is new version with 3 conductor cable.

Step 1. De-solder original pickups from S1 Harness. Note: some may have 3 wires.

Step 2. Install the new pickups and solder wires as shown in the diagram.

Note: the original existing wiring should appear exactly as it does in the diagram.

