

Install guide for Kinman Tele pickups (2C) in Fender S1 system.

23-Feb-08

For Kinman Tele neck pickups with 2 conductor cable (Red inner + Shield)
For 3 conductor cable (Red & Blue inner + Shield) use "Install guide for Kinman Tele pickups (3C) in Fender S1 system"

Step 1. De-solder original pickups from S1 Harness. Note: some may have 3 wires.

Step 2. Install the new pickups and solder wires as shown in the diagram.

Note: the original existing wiring should appear exactly as it does in the diagram.

