

Install guide for Kinman Tele pickups (2C) in original harness.

2-July-08 Rev-0

Step 1. Note the connections of the existing pickups with a sketch.

Note: the original existing wiring does not have to appear exactly as it does in the diagram.

Step 2: De-solder original pickups from Harness.

Step 3. Install the new pickups and solder wires as shown in the diagram.

